



Kit ESCo EW8BX

Focus your energy

EW8BX

Electrical switchboards prepared and configured for easy installation.

EW8BX2A0A33

Electrical switchboard prepared and configured with: 1 Data Manager (1 LAN, 1 RS485 , 1 USB, 3 I/Os) with preinstalled Energyaware basic software, 2 DTM base (energy meters with external TA), power supply, 3PN fuse switch disconnecter, terminal blocks for Data Manager I/Os

EW8BX2A0B33

Electrical switchboard prepared and configured with: 1 Data Manager (1 3G interface, 1 LAN, 1 RS485 , 1 USB, 3I/Os) with preinstalled Energyaware basic software, 2 DTM base (energy meters with external TA), power supply, 3PN fuse switch disconnecter, terminal blocks for Data Manager I/Os

EW8BX2A0C33

Electrical switchboard prepared and configured with: 1 Data Manager (1 WiFi, 1 LAN, 1 RS485 , 1 USB, 3I/Os) with preinstalled Energyaware basic software, 2 DTM base (energy meters with external TA), power supply, 3PN fuse switch disconnecter, terminal blocks for Data Manager I/Os

EW8BX2A0D33

Electrical switchboard prepared and configured with: 1 Data Manager (1 LAN, 1 RS485, 1 RF868, 1 USB, 3 I/Os) with preinstalled Energyaware basic software, 2 DTM base (energy meters with external TA), power supply, 3PN fuse switch disconnecter, terminal blocks for Data Manager I/Os

EW8BX3A0000

Electrical switchboard prepared and configured with: 3 DTM base (energy meters with external TA), 3PN fuse switch disconnecter

EW8BX3C0000

Electrical switchboard prepared and configured with: 3 DTM base (energy meters with external TA and RF868), 3PN fuse switch disconnecter

EW8BX2B0A33

Electrical switchboard prepared and configured with: 1 Data Manager (1 LAN, 1 RS485 , 1 USB, 3 I/Os) with preinstalled Energyaware basic software, 2 DTM with 2 I/Os (energy meters with external TA), power supply, 3PN fuse switch disconnecter, terminal blocks for Data Manager I/Os

EW8BX2B0B33

Electrical switchboard prepared and configured with: 1 Data Manager (1 3G interface, 1 LAN, 1 RS485 , 1 USB, 3I/Os) with preinstalled Energyaware basic software, 2 DTM with 2 I/Os (energy meters with external TA), power supply, 3PN fuse switch disconnecter, terminal blocks for Data Manager I/Os

EW8BX2B0C33

Electrical switchboard prepared and configured with: 1 Data Manager (1 WiFi, 1 LAN, 1 RS485 , 1 USB, 3I/Os) with preinstalled Energyaware basic software, 2 DTM with 2 I/Os (energy meters with external TA), power supply, 3PN fuse switch disconnecter, terminal blocks for Data Manager I/Os

EW8BX3B0000

Electrical switchboard prepared and configured with: 3 DTM with 2 I/Os (energy meters with external TA), 3PN fuse switch disconnecter

