



EVERYWARE Tools

Codes	Description
EVERYWAREA0A0NN	EVERYWARE LICENCE Single Domain / Single Access
EVERYWAREA0B0NN	EVERYWARE LICENCE Single Domain / Multi Access
EVERYWAREA0C0NN	EVERYWARE LICENCE Multi Domain / Multi Access
EVERYWAREB0N0AN	EVERYWARE OEM RUNTIME LICENCE PC (ESA HARDWARE)
EVERYWAREB0N0BN	EVERYWARE OPEN RUNTIME LICENCE PC (NOT ESA HARDWARE)